

Rapid Preconcentration of Ra-226 in Hydraulic Fracturing Wastewater Samples for Gamma Spectrometry Assay

Sherrod L. Maxwell Senior Fellow Scientist

61st Annual Radiobioassay and Radiochemical Measurements Conference

October 26, 2015

Co-authors:

Dr. Dan McAlister, PG Research Dr. Richard Warren, SRNS Brian Culligan, SRNS

Background

- Need for rapid method to preconcentrate Ra-226 in hydraulic fracturing samples
 - Lower MDA
 - Rapid processing
- Challenges
 - Hard to collect Ra-226
 - High levels of dissolved solids: Ca, Ba, Sr, Mg, Na, K, etc.
 - Interference of U-235 on Ra-226 186 keV gamma ray
 - Waiting on Ra-226 progeny hurts turnaround times
- Wanted to use modification of SRNS methods for seawater to help solve the analytical issues

Literature

- A. Nelson et al, Matrix Complications in the Determination of Radium Levels in Hydraulic Fracturing Flowback Water from Marcellus Shale Environ. Sci. Technol. Lett., 2014, 1 (3), pp 204–208
 - very low chemical yields using a wide array of analytical approaches
 - sample processing problems associated with high levels of dissolved solids
 - 20g/L Ca, 10 g/L Ba, 10 g/L Sr
 - "alkaline earth nightmare"
 - Direct gamma spectrometry (precipitation problems)
 - using agar/heating to prevent precipitation of ultrafine particulate matter
 - ~80 pCi/L MDA
 - reliance on assumption U-235 is not present

Literature

- T. Zhang et al, Analysis of Radium-226 in High Salinity Wastewater from Unconventional Gas Extraction by Inductively Coupled Plasma-Mass Spectrometry Environ. Sci. Technol., 2015, 49 (5), pp 2969–2976
 - Need to remove isobaric interferences Ba + Sr using small amount of Sr Resin
 - Sr Resin ability to remove Ba can be easily exceeded with these samples
 - Some residual Ba noted in high Ba samples
 - Goal: 100 pCi/L MDA
 - No tracer noted!

	MSW composition (mg/L)							
sample	Na	Ca	Ba	Sr	TDS			
S1	11,500	3,440	1,060	808	28,500			
S2	23,000	6,880	2,120	1,620	57,000			
S3	46,000	13,760	4,230	3,230	114,000			
S4	69,000	20,640	6,360	4,850	171,000			
S5	11,500	3,440	1,060	808	28,500			
S6	46,000	13,760	4,240	3,230	114,000			
S 7	69,000	20,640	6,360	4,850	171,000			

What did not work for Ra-226...

- Calcium phosphate precipitation
 - 100 ml simulant might results in 80 ml ppt
- Direct barium sulfate precipitation
 - Nelson et al called "intractable"
- MnO₂ ppt (high Ba...)
- Iron hydroxide
- Nelson et al covered all this and more....

Got an idea....

- High Ca level is a major component in the "nightmare"
- Difficult to separate large amounts of alkaline earth metals
- Tried everything but there was one option left...

Contacted Dan McAlister, PG Research, and told him what I was thinking.....

Breakthrough!

- Calcium fluoride CaF₂ 5.3×10⁻⁹
- Strontium fluoride SrF₂ 2.5×10⁻⁹
- Magnesium fluoride MgF₂ 3.7×10⁻⁸
- Barium fluoride BaF₂ 1.0×10⁻⁶
- Let's acidify to 1.5M HCl, add HF to try to remove Ca and test...
- Then precipitate Ra/Ba sulfate with ammonium sulfate/ 10% ethanol
- Ca/some of Sr/Mg removed and 80-90% Ba/Ra chemical yield

Final Geometry


- Initially 500 ml polythylene bottle, BaSO₄ suspension
 - Hard to control/settled
- 250 ml Nalgene bottle with centrifuging (Dan McAlister)
 - Reproducible, even layer with varying thicknesses
- Used 356 keV gamma ray for Ba-133 tracer recovery
- Used Ba-133 81 keV gamma ray correlation with 186 keV Ra-226 gamma ray to correct for geometry/mass attenuation
 - Plot of 81keV efficiency vs. 186 keV gamma ray efficiency
 - Minor correction also in 356 keV Ba-133 from 81 keV as well (if needed)
 - low abundance gamma rays (~0.2%) Ra-226, Ra-224, Ra-223 near 81 keV so we use enough Ba-133 to minimize any impact
- What about U-235??


U-235 Gone...


- U removed with CaF₂ (at high levels) regardless for U⁺⁴ and U⁺⁶
- H₂O₂ added initially and all water rinses to ensure U⁺⁶
 - Additional U removal as U⁺⁶
- U removed 99.9%++

```
185.715 keV 57.0 % abundance
```

- Ra-226
 - 186.211 keV 3.64 % abundance
- Ba-133
 - 80.9979 keV 32.9 % abundance- 356.013 keV 62.05 % abundance








Not in simulant; Ce or Ca only

Rapid Preconcentration Method for Ra-226

Add Ba-133 tracer and 1ml 30 wt% H₂O₂ to sample aliquot in 250 ml or 500 ml tubes*. Add 50 ml 12M HCl per 400 ml sample aliquot. Mix well. * Some sample may need to be diluted with water 50% or more if silicates that cause cloudiness are high. Aliquots Add 20 ml 28M HF per 400 ml aliquot to each tube. and tracer may be split Cap and mix well. Centrifuge 10-20 minutes at 3000 between multiple tubes to rpm or more as needed until supernate is clear. increase total sample aliquot. Transfer supernate to 250 ml or 500 ml centrifuge tube. Add 0.5 ml 30 wt% H₂O₂ and mix well. Add 20 g ammonium sulfate to each tube. Add ~40 ml ethanol to each tube per 400 ml aliquot. Mix well and wait 10 to 15 minutes. Centrifuge 5 to 10 minutes. ** ** If samples were split between tubes, combine the respective barium sulfate precipitates in a single tube Discard supernate. Add 50-100 ml water, 0.2 ml 30 then rinse the combined wt% H₂O₂, mix well and centrifuge 5 minutes. precipitate with water and proceed. Transfer precipitate to 50 ml tube (or 250 ml tube if <2 hours! large) using 10-20 ml aliquots of water. Add 0.05 ml 30 wt% H₂O₂, mix well and centrifuge 5 minutes. Transfer to 250 ml wide mouth plastic bottle using Count by gamma 10-20 ml aliquots of water. Centrifuge at 1600-2000 spectrometry rpm in flat bottom centrifuge bucket.

Calcium + U/Th Removal





Discard CaF₂

Transfer supernate (Ra/Ba) to new tube

Precipitate Ra/Ba









Ammonium sulfate + \sim 10% ethanol H_2O_2 and water rinses –ensure no U-235

Transfer to 250 ml Bottle and Centrifuge




Flat BaSO₄ layer from 450 ml simulant





Efficiency Plot of Ra-226 vs Ba-133 (81 keV)



Ra-226 Eff.

Ba-133 Eff. (81 keV)

Also plotted as y = 0.0327ln(x) + 0.2156

Ra-226 in Simulant Measurements

	Simulant Aliquot	U-235 Added	Count Time	Ba-133 Yield	Ra-226 Added	Ra-226 Measured	Ra-226 Measured	Bias
	(ml)	(1388 pCi)	(min)	(%)	(pCi)	(pCi)	(pCi/L)	(%)
1	200	Yes	960	83.5	25.4	25.8	129.0	1.6
2	400	No	720	90.3	634.5	622.0	1555.0	-2.0
3	450	No	720	89.1	634.5	620.2	1378.2	-2.3
4	450	No	720	87.3	31.7	42.5	94.4	34.1
5	450	No	720	86.3	20.0	20.4	45.3	2.0
6	200	No	960	83.9	25.4	27.9	139.5	9.8
8	450	No	960	80.6	126.9	117.9	262.0	-7.1
9	900	No	960	82.0	126.9	118.2	131.3	-6.9
10	1800	Yes	960	71.2	126.9	138.8	77.1	9.4
			Avg.	83.8				4.3
			SD	5.71				12.7

Germanium Detector, 40% Relative Efficiency

SRNS Approach

- Remove Ca
- Remove U-235
- Precipitate Ra/Ba to preconcentrate Ra-226 (50-100x)
- Utilize Ba-133 tracer (81 keV and 356 keV)
- Eliminate need for mass attenuation curve
 - Variable Ba content drives size of precipitate
- No drying of samples
- No column work (Ra-226)
- Look at options to collect U/Th for assay

U/Th Processing Options

U/Th by gamma spectrometry

- Th-229 tracer for both? (U-232 has low gamma ray abundance)
- Fe/Ti hydroxide, water rinse, add 1 ml 12M HCl, dissolves in small volume
- Th-229 183.93 keV (0.14%) vs. U-235 185.72 keV (57%)
- If any resolution problems...we can separate U/Th using LaF₃
- U^{+6} in supernate, Th^{+4} in ppt . (HNO₃-H₃BO₃)
- Homogeneous liquid geometry: 200 ml simulant to 10 ml

U/Th by alpha spectrometry

- U-232/Th-229 tracers
- Fe/Ti hydroxide, water rinse, add HCl, LaF₃ (removes Fe/Ti)
- Redissolve LaF₃ in HNO₃-H₃BO₃ for separation
- Separate using TEVA +TRU Resin

Rapid Preconcentration Method for U/Th

Add Th-229 tracer to sample aliquot in 250 ml tubes. Add 50 mg Fe and 1ml 20% TiCl per 200 ml sample aliquot. Mix well.

Adjust pH to ~8.5 with NH₄OH. Cap and mix well. Centrifuge 5 minutes at 3000 rpm or more as needed until supernate is clear. Discard supernate.

Add 100 ml water (pH 8.7-8.9), mix well. Centrifuge and discard water rinse to remove Ca. Repeat once more with 50 ml water rinse.

U/Th together

Discard water rinse. Add 1ml 12 HCl to dissolve small Fe/Ti ppt and transfer to 50 ml tube. Rinse tube with 5 ml 1M HCl and transfer rinse to 50 ml tube.

Add 5 mg La, 0.5 ml 30 wt% H₂O₂, 2 ml 28M HF and mix well. Centrifuge 5 minutes to collect LaF₃ precipitate. Th⁺⁴ precipitates and U⁺⁶ stays in solution. Pour off supernate and collect for U-235 by gamma spectrometry.

U/Th separate or together

Redissolve LaF₃ precipitate with 4 ml 6M HNO₃, 1ml 3M HNO₃-0.25M H₃BO₃ and 4 ml 2M Al(NO₃) ₃. Mix well. Sample may be counted by gamma spectrometry or column extraction applied for assay by alpha spectrometry.

Add 2 ml 1M HCl to La/Th precipitate, 0.2 ml 30 wt% H₂O₂,.5 ml 28M HF. Mix well.

Can process U/Th together for alpha spectrometry or separate during LaF₃ step for gamma assay.



Thorium Tracer Yield

	Sample Aliquot	Th-229 Yield	Matrix	U-238
	(ml)	(%)	Ca/Ba/Sr (g/L)	% Removal
1	200	98.8	12.5/6.25/6.25	>99.5%
2	200	100.6	12.5/6.25/6.25	>99.5%
3	200	99.2	12.5/6.25/6.25	>99.5%
4	200	90.8	12.5/6.25/6.25	>99.5%
5	200	97.7	12.5/6.25/6.25	>99.5%
6	200	88.5	12.5/6.25/6.25	>99.5%
	Avg.	95.9		
	SD	5.0		

TRU Resin, 16 hour count, U-238 added to test U Removal

Summary



- Rapid method to preconcentrate Ra-226 developed
 - Removal of Ca is key
 - Up to 1.8L simulant tested
 - U-235 removed
 - 2 hours or less to prepare
- Geometry attenuation correction applied using Ba-133 (81 keV)
 - To Ra-226 based on plot of Ba-133 efficiency (81 keV) vs Ra-226 efficiency (186 keV)
 - And minor yield adjustment to Ba (356 keV) via 81 keV/356 keV efficiency plot
- Difficult matrix
 - 50-100 x preconcentration
 - MDA <20 pCi/L achieved
- U/Th may be preconcentrated for alpha or gamma spectrometry